















SOLID STATE RELAY & Accessories

※ **Notice:** the Solid State Relay should be using in max. Ambient temperature 40°C, the temperature will increase 10°C when increases per 1.25Amp. We recommend the correct usage with proper Heat Sink avoiding the malfunction caused by over temperature.

Heat Sink

Appearance	Size	Suitable Specification	Appearance	Size	Suitable Specification																																	
H050 	Size: 60mm×50mm 	<table border="1"> <thead> <tr> <th>Model No</th> <th>Length L(mm)</th> <th>Suitable SSR</th> </tr> </thead> <tbody> <tr> <td>H050-50</td> <td>50</td> <td>5A, 10A</td> </tr> </tbody> </table>	Model No	Length L(mm)	Suitable SSR	H050-50	50	5A, 10A	H100 	Size: 81mm×81mm 	<table border="1"> <thead> <tr> <th>Model No</th> <th>Length L(mm)</th> <th>Suitable SSR</th> </tr> </thead> <tbody> <tr> <td>H100-45</td> <td>45</td> <td>40A</td> </tr> <tr> <td>H100-70</td> <td>70</td> <td>50A</td> </tr> <tr> <td>H100-100</td> <td>100</td> <td>75A</td> </tr> <tr> <td>H100-120</td> <td>120</td> <td>90A</td> </tr> <tr> <td>H100-150</td> <td>150</td> <td>100A,125A</td> </tr> </tbody> </table>	Model No	Length L(mm)	Suitable SSR	H100-45	45	40A	H100-70	70	50A	H100-100	100	75A	H100-120	120	90A	H100-150	150	100A,125A									
Model No	Length L(mm)	Suitable SSR																																				
H050-50	50	5A, 10A																																				
Model No	Length L(mm)	Suitable SSR																																				
H100-45	45	40A																																				
H100-70	70	50A																																				
H100-100	100	75A																																				
H100-120	120	90A																																				
H100-150	150	100A,125A																																				
H060 	Size: 60mm×50mm 	<table border="1"> <thead> <tr> <th>Model No</th> <th>Length L(mm)</th> <th>Suitable SSR</th> </tr> </thead> <tbody> <tr> <td>H060-50</td> <td>50</td> <td>10A,15A</td> </tr> <tr> <td>H060-80</td> <td>80</td> <td>25A</td> </tr> <tr> <td>H060-100</td> <td>100</td> <td>40A</td> </tr> <tr> <td>H060-120</td> <td>120</td> <td>50A</td> </tr> <tr> <td>H060-150</td> <td>150</td> <td>75A</td> </tr> </tbody> </table>	Model No	Length L(mm)	Suitable SSR	H060-50	50	10A,15A	H060-80	80	25A	H060-100	100	40A	H060-120	120	50A	H060-150	150	75A	H104 	Size: 81mm×81mm 	H104-series for 3 phase SSR <table border="1"> <thead> <tr> <th>Model No</th> <th>Length L(mm)</th> <th>Suitable SSR</th> </tr> </thead> <tbody> <tr> <td>H104-104</td> <td>104</td> <td>25A, 40A</td> </tr> <tr> <td>H104-120</td> <td>120</td> <td>50A</td> </tr> <tr> <td>H104-150</td> <td>150</td> <td>75A</td> </tr> <tr> <td>H104-200</td> <td>200</td> <td>90A,100A,125A</td> </tr> </tbody> </table> <p><i>Note): It depends on the condition of discharge heat for adding the Fan to cool forcibly.</i></p>	Model No	Length L(mm)	Suitable SSR	H104-104	104	25A, 40A	H104-120	120	50A	H104-150	150	75A	H104-200	200	90A,100A,125A
Model No	Length L(mm)	Suitable SSR																																				
H060-50	50	10A,15A																																				
H060-80	80	25A																																				
H060-100	100	40A																																				
H060-120	120	50A																																				
H060-150	150	75A																																				
Model No	Length L(mm)	Suitable SSR																																				
H104-104	104	25A, 40A																																				
H104-120	120	50A																																				
H104-150	150	75A																																				
H104-200	200	90A,100A,125A																																				
H080 	Size: 70mm×70mm 	<table border="1"> <thead> <tr> <th>Model No</th> <th>Length L(mm)</th> <th>Suitable SSR</th> </tr> </thead> <tbody> <tr> <td>H080-50</td> <td>50</td> <td>25A</td> </tr> <tr> <td>H080-100</td> <td>100</td> <td>40A</td> </tr> <tr> <td>H080-150</td> <td>150</td> <td>50A</td> </tr> </tbody> </table>	Model No	Length L(mm)	Suitable SSR	H080-50	50	25A	H080-100	100	40A	H080-150	150	50A	H197-100 	Size: 158mm×35mm 	H197-100 for 3 phase SSR <table border="1"> <thead> <tr> <th>Model No</th> <th>Length L(mm)</th> <th>Suitable SSR</th> </tr> </thead> <tbody> <tr> <td>H197-100</td> <td>100</td> <td>25A, 40A</td> </tr> </tbody> </table>	Model No	Length L(mm)	Suitable SSR	H197-100	100	25A, 40A															
Model No	Length L(mm)	Suitable SSR																																				
H080-50	50	25A																																				
H080-100	100	40A																																				
H080-150	150	50A																																				
Model No	Length L(mm)	Suitable SSR																																				
H197-100	100	25A, 40A																																				
H120 	Size: 104mm X 80mm 	<table border="1"> <thead> <tr> <th>Model No</th> <th>Length L(mm)</th> <th>Suitable SSR</th> </tr> </thead> <tbody> <tr> <td>H120-80</td> <td>80</td> <td>25A, 40A</td> </tr> <tr> <td>H120-100</td> <td>100</td> <td>50A</td> </tr> <tr> <td>H120-120</td> <td>120</td> <td>75A</td> </tr> <tr> <td>H120-150</td> <td>150</td> <td>90A, 100A, 125A</td> </tr> </tbody> </table>	Model No	Length L(mm)	Suitable SSR	H120-80	80	25A, 40A	H120-100	100	50A	H120-120	120	75A	H120-150	150	90A, 100A, 125A																					
Model No	Length L(mm)	Suitable SSR																																				
H120-80	80	25A, 40A																																				
H120-100	100	50A																																				
H120-120	120	75A																																				
H120-150	150	90A, 100A, 125A																																				



Option Accessory **Model: RAIL-S** (For H050/H060/H080 Heat Sink)
Model: RAIL-L (For H100/H104/H120 Heat Sink)

